

# BioLogic mini Set Up and Replacement Guide

1



Position the device on a surface

2



Grip the base and the cap of the device

3



Turn the cap counterclockwise

4



Remove the cap

5



Open the ENVIROBIOTICS bottle, keep upright

6



Place the device over the bottle

7



Screw the bottle into the base until tight

8



Turn the device over and place on a surface

9



Put the cap on the device, turn clockwise

10



The device is ready, please read the operating instructions

## Operations

The BioLogic mini has two operating modes - **Automatic** and **Spray**.

### Automatic mode

This is the default mode for your BioLogic mini which provides 24/7 automatic and continuous operation. Your ENVIROBIOTICS refill should last between 11-12 weeks in automatic mode.

### Spray mode

Spray mode is for when you would like to apply an immediate, heavier fogging to a contaminated area. When you press the [Spray] button, the device will continuously disburse ENVIROBIOTICS for 30 seconds. After the 30 seconds the device automatically returns to Automatic Mode. When spraying, hold the device upright, and make sure to spray over any area or object you would like to cover. Effective in any space!

### Shutting down the device

Press and hold the power button for about 3-4 seconds. The LED will go out, and the device will be off.

### LED color indications:

**Steady Green:** the device is in automatic mode

**Blinking Green:** indicates the device is dispersing ENVIROBIOTICS.

**Blinking Red:** indicates low liquid level, and a beep will be activated.

**Blinking Orange:** indicates low battery / recharging required.

**Steady Orange:** indicates the unit is charging.

### Charging The BioLogic mini

Connect the USB charging cord to the device, and charge for two to three hours until the battery indicator LED is white.



## Safety Guidelines:

1. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
2. Children should be supervised to ensure that they do not play with the appliance.
3. Please follow the Replacement Guide for filling.
4. Unplug the appliance during filling and cleaning.
5. This appliance contains batteries that are only replaceable by skilled persons.

## Specifications:

SKU:	30230
Power connection:	USB Type-C
Power:	Rechargeable Li-Ion battery
Rating:	DC 3.7V = 1A
Coverage:	up to 300 square feet
Runtime:	approximately 3 months

## Certificates:



[www.EnviroBiotics-Asia.com](http://www.EnviroBiotics-Asia.com)

Please visit "website>support>manuals & download" for soft copy



**ENVIROBIOTICS**  
ENVIRONMENTAL PROBIOTICS

# BioLogic Mini

Probiotic Purification for Surfaces, Objects & Air

Quik Start Guide